

NEW

Giant Taste & Odor Cartridges Model

Problem:

Unpleasant tastes and odors, such as chlorine and/or sulfur (rotten egg), in your water

Solution:

The Keystone GIANT Taste and Odor Cartridge

Keystone Filter's standard economical wound carbon cartridge (#310) that you have come to rely on is now available in a Giant version. Like the standard cartridge, this Giant version is made of activated carbon fiber which is proven to remove bad tastes and odors by adsorption. The Giant cartridge is tightly wound and uses very fine activated carbon particles to maximize adsorption efficiency. This economical Giant cartridge is also cellulose-free, making it ideal for well water applications.

Now you can remove tastes and odors throughout the entire house with one easy-to-replace cartridge. Use a 10" cartridge for smaller homes or couple two cartridges together for large homes or other larger applica-

Specifications

MODEL NUMBER	MICRON RATING	MAXIMUM OPERATING TEMP. °F (°C)	FLOW RATE (GPM)	CARTRIDGE SIZE (IN.)	SHIPPING WEIGHT/CART. (LB.)
G310	10.0	100 (38)	8	9.75 X 4.5	2.0

Chlorine Reduction Capacity: > 8,000 gallons at 2.5 GPM. Capacity is based upon 80% reduction of chlorine in water using

Outstanding chlorine reduction at an economical price

- Longer life
- Higher flow
- Fits Keystone GIANT and comparable large diameter housing
- Non-cellulose

Materials of Construction

- Carbon impregnated polyester filter media
- Polyester inner layer
- Polypropylene core and shroud
- Plastisol endcaps

Warnings

Operating conditions can change performance. Actual results will vary depending on combinations and amounts of organic contaminants, changes in pH or other conditions encountered in actual use.

USE KEYSTONE FILTERS ONLY WITH MICROBIOLOGICALLY SAFE WATER.

All information presented here is based on data believed to be reliable. It is offered for evaluation and verification, but is not considered to be a warranty of any kind.

Now ORDER Keystone products ONLINE at www.thomas-register.com/keystonefilter



Keystone Filter Divi-

2385 North Penn Road, Hatfield, PA 19440
Toll Free: (800) 822-1963, FAX: (215) 997-1839
E-mail: filters@keystonefilter.com
Web Sites: www.keystonefilter.com

